

Greetings,

Here are some instructions on using the New Heat Deflector with the old Elevator.

Using New Heat Deflector

Instead of the three tab Heat Deflector we are now just using the circular Pizza/Fire Stone or the HD2 Ceramic Deflector in two pieces (shown below). You can use just one half for two temperature zones.

To do this the Elevator is used with the Triangle down and support legs coming up to the Cooking Grid.

The deflector stone rests on the triangle and the Cooking Grid rests on the 3 Support Legs.

(scroll down)

OLD 3 Tab HD



NEW HD Arrangement



Sometimes the Support Legs need to be bent in just a little bit so bar around the perimeter of the cooking grid may slip down and rest over it. This keeps the grid from moving around. (See Photos)

Unless one support leg is not the same as the others they should all be bent in a little until it fits.

